



Step 1: Flatness Measurement

Use a straight edge to measure the flatness of the stone. Lay the straight edge down to the surface and try sliding a piece of paper between the straight edge and stone to check the possible gap to determine whether it needs flattening.



Step 2: Soak and mark the stone

Soak the stone for around 10 minutes until bubbles disappear. Then use a pencil to mark lines on your stone.




Step 3: Flattening Stone

Rub the stone surface against the lapping plate and keep an eye on the pencil marks. Once the marks have worn away, the flattening is finished.

Method 1



Method 2



Maintenance: Rinse the lapping plate thoroughly and always keep it dry when storing the diamond stone.

*Watch its demo video on YouTube:

bit.ly/145HVideo

Or scan QR code



*Each SHARPAL product is warranted to be free from defects in material and workmanship for **3 years** from the date of purchase under normal wear and tear, except for damage caused by misuse or alteration. THIS WARRANTY APPLIES ONLY TO NON-INDUSTRIAL OR NON-COMMERCIAL USE. If you want to make a warranty claim, please contact us through SHARPAL website or send an email directly to warranty@sharpal.com.